

Camshaft Mounting Tool Set for VAG & Porsche (Art. 9319)



PRO+



- for installation of camshafts in the correct position
- required when installing of new or existing camshafts, an installation without this tool can cause damage to the camshaft bearing bridge and cylinder head
- suitable for the following diesel vehicles (TDI CR) as of 2003
Audi, Porsche, Seat, Skoda, Volkswagen

1.2 - 1.6 - 2.0 - 2.7 - 3.0 - 4.0 - 4.2 Common-Rail engines,

engine codes: ASB, ASE, BKN, BKS, BMK, BNG, BPP, BSG, BTR, BUG, BUN, BVN, CAAA, CAAB, CAAC, CAAD, CAAE, CAGA, CAGB, CAGC, CAHA, CAHB, CAMA, CAMB, CANA, CANB, CANC, CAND, CAPA, CARA, CASA, CASB, CASC, CASD, CATA, CAYA, CAYB, CAYC, CAYD, CAYE, CBAA, CBAB, CBAC, CBBA, CBBB, CBDA, CBDB, CBDC, CCFA, CCFC, CCHA, CCHB, CCLA, CCMA, CCWA, CCWB, CDBA, CDCA, CDSB, CDTA, CDTB, CDUC, CDUD, CDYA, CDYB, CDYC, CEGA, CEXA, CFCA, CFFA, CFFB, CFFD, CFFE, CFGB, CFGC, CFGD, CFHA, CFHB, CFHC, CFHD, CFHE, CFHF, CFJA, CFWA, CGKA, CGKB, CGLA, CGLB, CGLC, CGLD, CGLE, CGQB, CJAA, CJCA, CJCB, CJCC, CJCD, CJGA, CJGC, CJGD, CJMA, CKDA, CKTB, CKTC, CKUB, CKUC, CKVB, CKVC, CLAA, CLAB, CLCA, CLCB, CLJA, CLLA, CLNA, CLZB, CMEA, CMFA, CMFB, CMGB, CMHA, CNEA, CNFA, CNRB, CRCA, CSHA, M05/9D (CAS),

Technical modifications reserved - we are not responsible for issues while printing

M05/9E, M05/9E (CRCA), M05/9E (CRCB)

- includes following tools:

- mounting device including pre-assembled parts,
to be used as OEM T40094
- camshaft retaining clamp,
to be used as OEM T40095
- 2x alignment clamps,
to be used as OEM T40096 & T40096/1
- 4x camshaft brackets for mounting device,
to be used as OEM T40094/1, T40094/2,
T40094/9, T40094/10
- locking tool for camshaft holder,
to be used as OEM T40094/11