

## 21-piece Ball Joint Assembly Set (Art. 1834)

PRO



- heavy duty model with 152 mm pressure fork opening
- the set includes all necessary bushes and pressure plates for changing the ball joints on most US, european SUV cars and Transporter
- 230 mm pressure spindle
- pressure spindle arm
- pressure bolt for pressure spindle 1/4" and 3/4" (long type)
- reception bushes 1-3/4 x 2" / 2-1/4"x 2-1/2" / 2-3/4"x 3"
- reception bushes 2-1/4" / 1-3/4" / 1-7/16" / 2-3/4" und 2-1/4"
- adaptor for reception bushes 2"
- reception cup 2" / 2-5/8" / 2" / 1-1/4" / 1-3/4"
- assembly cup 1-3/4"

Technical modifications reserved - we are not responsible for issues while printing