

Pliers for Earless Axle Boot Clamps (Art. 9093)

**PRO +**

- suitable for earless boot clamps on rubber and thermoplastic axle boots, installed in Audi, BMW, Chrysler, Ford, GM, Honda, Mazda, Mercedes, Nissan, Opel, Porsche, Volkswagen
- suitable for up to 100 mm clamp diameter, e.g. Oetiker 168

Technical modifications reserved - we are not responsible for issues while printing