

## VW / Audi Subframe Locating Pin Set (Art. 8306)

PRO +



- for precisely aligned mounting of the subframe
- needed e.g. for replacing the rubber bushings and all jobs for which the auxiliary frame (subframe) is removed
- suitable for:  
VW Scirocco (09), EOS (06), Golf (09), Golf Plus (05), Jetta (04-06), Polo (02), Fox (06), Passat (06), Passat CL (09), Audi A3 (04) and Audi A3 (04), TT (07), A4 (01)
- to be used as OEM T10096

Technical modifications reserved - we are not responsible for issues while printing