

Mounting Tool Set for flexible Multi Ribbed Belts (Art. 8301)



- allows damage free mounting of flexible multi-ribbed belts
- flexible belt drive requires no idler, but this special assembly tool
- suitable for the following models:
 - BMW: 118, 120, 318, 325, 330, 335, 520, 525, 530, 535, 635, 730, X3, X5 petrol and diesel engines
 - Chrysler Grand Voyager, Voyager
 - Citroen: C2, C3, C4, Jumper, Relay
 - Fiat Albea, Doblo, Marea, Multipla, Ducato, Fiorino, Fiorino Qubo, Linea, Palio, Siena, Stilo, Strada Pick Up, Lancia, Lybra
 - Ford C-Max, Focus, Mondeo, Tourneo, Transit, Courier, Fiesta, Fusion
 - Iveco Daily
 - Mazda 3, 5, Axela
 - Peugeot: 206, 207, 307, Boxer
 - VOLVO: C30, S40, V50
- contains 3 different special tools

Technical modifications reserved - we are not responsible for issues while printing