

Bearing Inner Ring Puller, 68 mm (Art. 9331)

**PRO+**

- for removing of e.g. inner wheel bearing rings on wheel hubs
- the bearing rings usually remain on the wheel hubs when disassembling the wheel bearing
- clamping device presses puller feet safely behind the component to be removed
- pressure piece diameter: 25 x 30 mm
- puller width: 68 mm
- puller depth: 60 mm