

OBD II (EOBD) Trouble Code Reader (Art. 63311)



- allows reading and deleting OBDII trouble codes
- no trouble code list required,
all trouble codes are displayed in plain text
- viewing the freeze frame values is an
important feature to locate a fault
- reading of readiness codes
indicates if emission systems are ready or not
- enables reading live data,
various parameters are shown in real time
- power supply via OBDII cable from the vehicle
- easy to use
- menu languages: German, English

- OBDII error code = motor control error codes
a reading of comfort and safety systems
such as Airbag, ABS, radio, heated seats, etc.
is not possible with the device

Technical modifications reserved - we are not responsible for issues while printing