

Digital Current Tester for Fuse Contact (Art. 63520)









- current measurements directly at the fuse box

- of cars and trucks
 helps to find "hidden" current
 to measure, remove the original fuse
 and connect the tester plug
 protection of the circuit is still provided
 by a fuse in the tester
- plugs both for mini fuse and standard fuse sockets

Technical modifications reserved - we are not responsible for issues while printing

Tel.: 02196 720480 Fax.: 02196 7204820 mail@bgs-technic.de